



**HYTORC**<sup>®</sup>  
Since 1968

**Tool Model: Stealth 8 with Hex Link**  
Pressure/Torque Conversion Chart

PRESSURE IN: PSI	TORQUE IN:			PRESSURE IN: BAR
	ft-lbs	KGM	NM	
1500	1199	166	1625	104
1600	1276	176	1730	110
1800	1431	198	1939	124
2000	1585	219	2149	138
2200	1743	241	2363	152
2400	1901	263	2578	165
2600	2060	285	2792	179
2800	2218	307	3006	193
3000	2376	329	3221	207
3200	2539	351	3442	220
3400	2702	374	3663	234
3600	2865	396	3884	248
3800	3028	419	4105	262
4000	3191	441	4326	276
4200	3354	464	4547	290
4400	3517	486	4768	303
4600	3681	509	4989	317
4800	3844	532	5211	331
5000	4007	554	5432	345
5200	4172	577	5656	358
5400	4337	600	5879	372
5600	4502	623	6103	386
5800	4667	645	6327	400
6000	4832	668	6550	414
6200	4988	690	6762	427
6400	5145	712	6974	441
6600	5301	733	7186	455
6800	5458	755	7398	468
7000	5614	776	7610	482
7200	5773	798	7825	496
7400	5931	820	8040	510
7600	6090	842	8255	524
7800	6248	864	8470	538
8000	6407	886	8685	552
8200	6565	908	8900	565
8400	6723	930	9114	579
8600	6881	952	9328	593
8800	7039	973	9542	607
9000	7197	995	9756	620
9200	9354	1017	9970	634
9400	7512	1039	10183	648
9600	7669	1061	10396	662
9800	7827	1082	10610	676
10000	7984	1104	10823	690

**Hytorc West**

<http://www.hytorcwest.com>

## Important Safety Instructions

**WARNING:** Your **HYTORC TORQUE MACHINE** is a power tool, and as with any power tool, certain safety precautions should be observed to avoid accidents or personal injury. The following tips will assist you.

- **READ ALL INSTRUCTIONS.**
- **KEEP WORK AREA CLEAN AND WELL LIT.**
- **CONSIDER WORK AREA ENVIRONMENT.** Electrical Pumps should never be used in any atmosphere which can be considered potentially volatile. If there is any doubt, use an air pump. Also Note: metal to metal contact can cause sparks, precautions should be taken.
- **AVOID PREMATURE TOOL STARTING.** The Pump Remote Control is for the TOOL OPERATOR only.
- **STAY CLEAR DURING OPERATION.** In most cases, the tool will allow “hands free” operation. If the tool must be held or steadied during operation, use alternative means of securing the tool to the application.
- **GUARD AGAINST ELECTRIC SHOCK.** Ensure the pump is properly grounded and the proper voltage is being used.
- **STORE IDLE TOOLS.** When not in use, tools and accessories should be properly stored to avoid deterioration.
- **USE RIGHT TOOL.** Don't force small tools or attachments to do the job of a larger tool. Don't use tool for purposes not intended.
- **PROPER SAFETY ATTIRE.** When handling/operating hydraulic equipment, use work gloves, hard hats, safety shoes and other applicable clothing.
- **USE SAFETY GLASSES.**
- **Moving equipment.** Do not use hydraulic hoses, uniswivels, pump power or remote cords as means of moving the equipment.
- **MAINTAIN TOOLS WITH CARE.** For top performance, inspect tool, powerpack and accessories for visual damage frequently and always prior to use. Always follow instructions for proper tool and pump maintenance. Refer to the Operations maintenance Section for further clarification.
- **STAY ALERT.** Watch what you are doing. Use common sense. Do not use power equipment under the influence of any mood altering substances.
- **PRIOR TO OPERATION.**  
Ensure that all hydraulic connections are securely connected and there is no leakage.  
Verify that the hydraulic hoses are not kinked or otherwise damaged.  
Insure the square drive and its retainer is fully and securely engaged.  
Ascertain that all connectors, elbows, fittings and swivels are not bent, loose or damaged.
- **PRIOR TO USE.**  
Check Sockets for size, quality and flaws. (Do not use if question able.)  
Cycle tool to ensure proper function.  
Locate a solid, secure reaction point.  
Be sure the reaction arm retaining clamp is fully engaged.  
Be sure the hydraulic hoses are free of the reaction point.  
Pressurize the system momentarily if the tool tends to “ride up” or to “creep”, stop and re-adjust the reaction arm to a more solid and secure position.  
  
NOTE: Remain clear of the reaction arm during operation and never put body parts between reaction arm and reaction surface.
- **ALWAYS USE QUALITY ACCESSORIES.** Always use top quality impact sockets in good condition which are the correct size and fully engage the nut. Hidden flaws, however, remain a possibility which could cause break, so stay clear of sockets during operation.
- **DO NOT USE** other equipment to enhance performance. (Hammer on Socket/Tool)
- **NOTE:** HYTORC Pumps are designed to operate HYTORC Tools only. Damage may occur to the pump or product that is being operated due to misuse.

**SAVE THESE INSTURCTIONS FOR FUTURE USE!**